




MULTIMATRIX 6/24 RHP

SPARE PARTS REFERENCE CODES



POS.	CODE	DESCRIPTION
1	A0100100.409	Screw
2	A0100100.066	Screw
3	A0903326.404	Spring
4	FAET8000	Screw
5	---	Not Used
6	A0201000.294	Pinch
7	FAETKJ00	Spacer
8	A0201000.032	Pinch
9	A0802705.145	Pin
10	A0903200.134	Spring
11	A0903200.134	Spring
12	A1202001.252	Ball Plunger
13	A1700005.361	Sphere
14	A4204826.239	Push Rod
15	FAAIEZ00	Reference Pin
16	FAAITV00	Stripper Lock Ring Nut
17	FAETAB00	Ram
18	FAAKAF00	Guide
19	FAETAM00	Ram Guide
20	FAETAS00	Punch Bearing
21	FAETER00.XXX	Pin Guide
22	FAAKES00	Washer
23	FAAKEF00.XXX	Die Holder
24	A0201000.048	Pinch
25	---	Punch
26	---	Die
27	---	Stripper
---	FAAITZ00	Stripper Opening Tool
---	FA95EZ00	Brass Ram
---	A1103929.266	Screwdriver
---	F248PU00	Jar of Grease